

# Nissan NV Installation Instructions

- 1.) Follow instructions 1-3 on the Topper Van Rack Installation guide.
- 2.) Secure supports to the factory mounting positions on the roof of the van (see fig. 1). Please note: A standard 1/2" wrench will not fit under the factory mounting positions to secure the supports. Therefore, a tool has been provided.
- 3.) For Heavy Duty Kits (added center supports), a 1/4" shim MUST be placed under the front two supports to accommodate for the bow in the roof of the van (see fig. 2).
- 4.) With help, turn the rack over and set it in the pockets on top of the van roof.
- 5.) Adjust the rack in the support pockets so that the second to the last crossbar is just behind the last support. (see fig. 2) This position will leave the rack to overhang the rear of the van just enough to easily allow the user to slide ladders and material onto the rack without hitting the van.
- 6.) After clamping the rack in the desired position, drill out each of the holes in the supports through the siderails using an 11/32" drill bit.
- 7.) Secure the siderails in the support pockets using 2 - 5/16" x 2" hex bolt, 5/16" flat washer, and 5/16" nylock nut in each support pocket.

